


RUSSIAN MILITARY

& outdoor

BAIKAL MP-654K BARREL REPLACEMENT PROCEDURE

1. Position the existing barrel in the vice and rotate the pistol grip anti-clockwise

2. DANGER ! at the final stage of unscrewing the barrel, the magazine guide will be pushed upwards (see arrow) by the spring violently -cover the guide with cloth to prevent injuries



Magazine guide

ALWAYS wear protective gloves and safety glasses !

3. Screw the new barrel in and install recoil spring back onto the new barrel with the tight end of the spring directed towards the pistol

Anyone involved in the above procedure does so at their own risk !
If in doubt, seek professional assistance from your local gunsmith
© FSU CONNECTIONS LTD

www.rusmilitary.com

